Service Manual
'Click' to download complete Manual

dition: November 13, 2008

LEXMARK™

Lexmark T650, T652, T654

InfoPrint 1832, 1852, and 1872

fineline6

Edition: November 13, 2008

service-repairmanual.com

InfoPrint 1832, 1852, and 1872

- ***Table of contents***
- ***Start diagnostics***
- ***Safety and notices***
- ***Trademarks***
- ***Index***

fineline6

service@repairmanual.com

Edition: November 13, 2008

The following paragraph does not apply to any country where such provisions are inconsistent with local law: LEXMARK INTERNATIONAL, INC. PROVIDES THIS PUBLICATION “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

Comments may be addressed to Lexmark International, Inc., Department D22X/002-1, 740 West New Circle Road, Lexington, Kentucky 40550, U.S.A or e-mail at ServiceInfoAndTraining@Lexmark.com. Lexmark may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

References in this publication to products, programs, or services do not imply that the manufacturer intends to make these available in all countries in which it operates. Any reference to a product, program, or service is not intended to state or imply that only that product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any existing intellectual property right may be used instead. Evaluation and verification of operation in conjunction with other products, programs, or services, except those expressly designated by the manufacturer, are the user’s responsibility.

Lexmark, Lexmark with diamond design, and MarkNet are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

PCL® is a registered trademark of the Hewlett-Packard Company.

All other trademarks are the property of their respective owners.

© 2008 Lexmark International, Inc.
All rights reserved.

UNITED STATES GOVERNMENT RIGHTS
This software and any accompanying documentation provided under this agreement are commercial computer software and documentation developed exclusively at private expense.

P/N 12G9824

fineline6

Table of contents

Table of contents . . . iii
Notices and safety information . . . xiii
Laser notice . . . xiii
Lithium warning . . . ii-xix
Safety information . . . xix
Preface . . . xxii
Conventions . . . xxii
General information . . . 1-1
Maintenance approach . . . 1-1
Options . . . 1-2
Available internal options . . . 1-2
Media handling options . . . 1-2
Printer configurations . . . 1-3
Basic model . . . 1-3
Fully configured model . . . 1-4
Supported paper sizes, types, and weights . . . 1-6
Paper sizes supported by the printer . . . 1-6
Paper types and weights supported by the printer . . . 1-7
Paper types and weights supported by the output bins . . . 1-7
Tools required . . . 1-8
Acronyms . . . 1-9
Diagnostic information . . . 2-1
Start . . . 2-1
Confirm the installation status . . . 2-2
Power-on Reset sequence . . . 2-2
Entering Diagnostics mode . . . 2-2
User attendance messages . . . 2-3
Error code table 1 . . . 2-11
Service checks . . . 2-120
Sensor (input) service check . . . 2-120
Sensor (fuser output) service check . . . 2-120
Sensor (narrow media) service check . . . 2-121
Sensor (duplex input) service check . . . 2-121
Sensor (duplex input) service check (external duplex only) . . . 2-122
Sensor (duplex exit) service check (external duplex only) . . . 2-122
Sensor (pass through) service check . . . 2-123
Sensor (envelope feeder empty) service check . . . 2-123
Sensor (input) late jam service check. . . . 2-123
Sensor (input) lingering jam service check. . . . 2-126
Sensor (input) early jam service check . . . 2-128
Sensor (input) static jam service check . . . 2-130
Sensor (fuser output) late jam service check. . . . 2-130
Sensor (fuser output) lingering jam service check. . . . 2-132
Sensor (fuser output) static jam service check . . . 2-133
Sensor (narrow media) late jam service check. . . . 2-134
Sensor (narrow media) static jam service check . . . 2-135
Sensor (duplex input) late jam service check. . . . 2-136
Sensor (duplex input) lingering jam service check. . . . 2-137
Sensor (duplex input) static jam service check. . . . 2-139
Sensor (pass through) late jam service check . . . 2-140

service-repairmanual.com

fineline6

Sensor (pass through) lingering jam service check. 2-141
Sensor (pass through) static jam service check 2-142
Sensor (stapler pass through) late jam service check 2-143
Sensor (stapler pass through) lingering jam service check 2-144
Sensor (stapler pass through) static jam service check 2-144
Sensor (output pass through) late jam service check 2-145
Sensor (output pass through) lingering jam service check 2-146
Sensor (output pass through) static jam service check 2-147
Sensor (mailbox empty) late jam service check 2-148
Sensor (mailbox empty) lingering jam service check 2-149
Sensor (mailbox empty) static jam service check 2-149
Sensor (toner empty) service check 2-150
NVRAM mismatch failure (950.00 through 950.29) service check 2-150
. 2-151
Image quality trouble 2-152
Printer Related Troubleshooting 2-152
Image quality symptoms 2-152
Image Quality 2-153
Faint print (Low contrast) 2-153
Blank print (no print) 2-155
Solid black 2-157
Vertical lines and bands (process direction) 2-158
Horizontal white stripes or bands (side to side direction) 2-159
Vertical stripes (process direction) 2-160
Horizontal stripes (side to side direction) 2-161
Partial lack 2-163
Spots 2-164
After image 2-166
Background (fog) 2-167
Skew 2-168
Media damage 2-169
No fuse 2-171
Network service check 2-172

Diagnostic aids 3-1

Understanding the printer control panel 3-1
Accessing service menus 3-2
Diagnostics mode 3-3
Entering Diagnostics mode 3-3
Available tests 3-3
Exiting Diagnostics mode 3-5
REGISTRATION 3-5
Quick Test 3-6
PRINT TESTS 3-7
Input source tests 3-7
Print quality pages (Prt Quality Pgs) 3-7
HARDWARE TESTS 3-8
Panel Test 3-8
Button Test 3-8
DRAM Test 3-8
USB HS Test Mode 3-9
DUPLEX TESTS 3-9
Quick Test (duplex) 3-9
Top Margin (duplex) 3-10
Sensor Test (duplex) 3-10
Motor Test (duplex) 3-10
Duplex Feed 1 3-11
Duplex Feed 2 3-11
INPUT TRAY TESTS 3-11

service-repairmanual.com

fineline6

Feed Tests (input tray) . . . 3-11
Sensor Test (input tray) . . . 3-12
OUTPUT BIN TESTS . . . 3-12
Feed Tests (output bins) . . . 3-12
Feed To All Bins . . . 3-13
Sensor Test (standard output bin) . . . 3-13
Sensor Test (Output Expander) . . . 3-13
Sensor Test (high capacity output stacker) . . . 3-14
Sensor Tests (5-bin mailbox) . . . 3-14
Diverter Test . . . 3-14
StapleSmart FINISHER TESTS . . . 3-15
Staple Test . . . 3-15
Feed Tests (finisher) . . . 3-15
Sensor Test (finisher) . . . 3-15
BASE SENSOR TEST . . . 3-16
PRINTER SETUP . . . 3-16
Defaults . . . 3-16
Printed Page Count . . . 3-16
Perm Page Count (permanent page count) . . . 3-16
Serial Number . . . 3-16
Engine Setting 1 through 16 . . . 3-17
Model Name . . . 3-17
Configuration ID . . . 3-17
Edge to Edge . . . 3-17
EP SETUP . . . 3-18
EP Defaults . . . 3-18
Fuser Temperature (Fuser Temp) . . . 3-18
Fuser Page Count . . . 3-18
Warm Up Time . . . 3-18
Transfer . . . 3-18
Print Contrast . . . 3-18
Charge Roll . . . 3-18
Gap Adjust . . . 3-18
Auto Dark Adj . . . 3-18
REPORTS . . . 3-19
EVENT LOG . . . 3-19
Display Log . . . 3-19
Print Log . . . 3-19
Clear Log . . . 3-20
EXIT DIAGNOSTICS . . . 3-20
Configuration menu (CONFIG MENU) . . . 3-21
Entering Configuration Menu . . . 3-21
Available menus . . . 3-21
Maintenance page count (Maint Cnt Value) . . . 3-21
Maintenance page counter reset (Reset Cnt) . . . 3-22
Print quality pages (Prt Quality Pgs) . . . 3-22
Reports . . . 3-22
SIZE SENSING . . . 3-24
Panel Menus . . . 3-24
PPDS Emulation . . . 3-24
Demo Mode . . . 3-24
Factory Defaults . . . 3-24
LES Applications . . . 3-25
Energy Conserve . . . 3-25
Paper Prompts . . . 3-25
Env Prompts . . . 3-25
Action for Prompts . . . 3-25
Font Sharpening . . . 3-25
Wiper Messages . . . 3-25

service-repairmanual.com

fineline6

Clear Custom Status **3-25**
Best Speed **3-25**
Exit Config Menu **3-26**
Printer overview **3-27**
Basic model 3-27
Printer theory **3-28**
InfoPrint 1832 with duplex, paper path, rolls, and sensors **3-28**
InfoPrint 1852 and 1872 paper path rolls and sensors **3-29**
Functions of main components **3-29**
Media tray assembly 3-29
Rear media guide 3-29
Side guide 3-30
Wear strips 3-30
Media tray assembly **3-30**
Detection of media size 3-31
Pick arm assembly 3-31
Switch (media size) 3-32
Sensor (media empty) 3-32
Sensor (media low) 3-33
Multi-purpose feeder (MPF) **3-33**
MPF feed roll 3-33
MPF pick solenoid 3-33
Sensor (MPF media empty) 3-34
Supported paper sizes, types, and weights **3-34**
Paper sizes supported by the printer 3-34
Registration **3-36**
Sensor (input) 3-36
Aligner assembly 3-36
Transfer **3-37**
Transfer roll assembly 3-37
Polygon printhead assembly **3-38**
Oscillating printhead assembly **3-40**
Fuser **3-41**
Fuser components **3-41**
Heat roll 3-42
Pressure roll 3-42
Heater lamp 3-42
Thermal cutoff 3-42
Thermistor 3-42
Sensor (fuser output) 3-42
Sensor (narrow media) 3-42
Exit **3-43**
Sensor (standard bin full) 3-43
Drive **3-43**
Main drive motor assembly 3-43
Redrive motor assembly 3-43
Electrical components and controller **3-44**
Switch (printer front door interlock) 3-44
Main cooling fan 3-45
Print cartridge cooling fan 3-45
Duplex cooling fan 3-45
LVPS card assembly 3-45
HVPS card assembly 3-45
System card assembly 3-46
Control **3-46**
Printhead control **3-46**
Rotation of printhead motor 3-46
Determination of printhead ready 3-46
Printhead reference value 3-46

servicerepairmanual.com

fineline6

Fuser control **3-46**
Fuser control method 3-46
Fuser lamp on/off control 3-46
Fuser warm-up 3-47
Xerographic and print cartridge components **3-47**
Charge 3-48
Exposure 3-48
Development 3-49
Transfer 3-50
Cleaning 3-51
Auto density sensing 3-52
High Capacity Input Tray (HCIT) tray assembly **3-53**
250-sheet/550-sheet tray assembly **3-54**
Media size sensing 3-54
Media level sensing 3-55
Pick arm assembly 3-55
Switch (media size) 3-57
Sensor (media empty) 3-57
Sensor (media low) 3-57
Sensor (pass-thru) 3-57
Media transport path 3-59
InfoPrint 1832 paper path, rolls, and sensors **3-59**
InfoPrint 1852 and 1872 paper path, rolls, and sensors **3-60**
Functions of main components 3-60
Media tray assembly 3-60
Rear media guide 3-60
Side guide 3-60
Wear strips 3-61
Media tray assembly **3-61**
Detection of media size 3-61
Pick arm assembly 3-61
Switch (media size) 3-62
Sensor (media empty) 3-62
Sensor (media low) 3-62
Duplex **3-63**
Layout of media transport path 3-63
InfoPrint 1832 duplex paper path **3-63**
InfoPrint 1852 and 1872 duplex paper path **3-64**
Functions of main components 3-64
Sensor (duplex input) 3-64
Duplex drive motor assembly 3-65
Understanding jam numbers and locations **3-66**
200 and 201 paper jams **3-66**
202 and 203 paper jams **3-67**
230 paper jam **3-68**
Rear paper jams 3-68
Front paper jams 3-69
231-239 paper jams (optional external duplex unit) **3-70**
Rear paper jams 3-70
Front paper jams 3-70
241–245 paper jams **3-71**
250 paper jam **3-72**
260 paper jam **3-73**
271–279 paper jams **3-73**
280 paper jam **3-74**
281 paper jam **3-75**
282 paper jam **3-75**
283 staple jam **3-76**

Repair information 4-1

service-repairmanual.com

fineline6

Handling ESD-sensitive parts 4-1
Adjustments 4-2
Polygon and Oscillating printhead mechanical registration adjustment 4-2
Oscillating printhead assembly electronic adjustment 4-3
Alignment assembly adjustment 4-4
Fuser solenoid adjustment 4-6
Gap adjustment 4-6
Removals 4-7
Charge roll assembly removal (InfoPrint 1832, 1852, and 1872) 4-7
Duplex assembly removal (InfoPrint 1852 and 1872) 4-8
Duplex cooling fan removal (InfoPrint 1852 and 1872) 4-9
Duplex drive motor assembly removal (InfoPrint 1852 and 1872) 4-10
Duplex input sensor assembly removal (InfoPrint 1852 and 1872) 4-11
Duplex guide assembly, front removal (InfoPrint 1852 and 1872) 4-11
Media turn guide removal (InfoPrint 1832, 1852, and 1872) 4-13
Fuser access door assembly removal (InfoPrint 1832, 1852, and 1872) 4-13
Main cooling fan removal (InfoPrint 1832, 1852, and 1872) 4-15
Fuser drive release linkage removal (InfoPrint 1832, 1852, and 1872) 4-16
Fuser unit assembly removal (InfoPrint 1832, 1852, and 1872) 4-17
Fuser wiper cover assembly removal (InfoPrint 1832, 1852, and 1872) 4-18
HVPS card assembly removal (InfoPrint 1832, 1852, and 1872) 4-19
Inner deflector removal (InfoPrint 1832, 1852, and 1872) 4-19
LCD screen bezel removal (InfoPrint 1832, 1852, and 1872) 4-20
Laser cover removal (InfoPrint 1832, 1852, and 1872) 4-21
Side cover, left removal (InfoPrint 1832) 4-23
Side cover, left removal (InfoPrint 1852 and 1872) 4-24
Option drive shaft removal (InfoPrint 1832, 1852, and 1872) 4-25
Main drive motor assembly removal (InfoPrint 1832, 1852, and 1872) 4-26
Alignment assembly removal (InfoPrint 1832, 1852, and 1872) 4-27
Output cover assembly removal (InfoPrint 1832, 1852, and 1872) 4-29
Media out actuator removal (InfoPrint 1832, 1852, and 1872) 4-29
Media support removal (InfoPrint 1832, 1852, and 1872) 4-30
Tray roller catch assembly removal (InfoPrint 1832, 1852, and 1872) 4-30
MPF cam gear removal (InfoPrint 1832, 1852, and 1872) 4-31
MPF lift plate assembly removal (InfoPrint 1832, 1852, and 1872) 4-31
MPF media out actuator removal (InfoPrint 1832, 1852, and 1872) 4-32
MPF pick roll assembly removal (InfoPrint 1832, 1852, and 1872) 4-32
MPF pick solenoid assembly removal (InfoPrint 1832, 1852, and 1872) 4-33
MPF tray door assembly removal (InfoPrint 1832, 1852, and 1872) 4-35
Operator panel latch assembly removal (InfoPrint 1832, 1852, and 1872) 4-38
Operator panel door assembly removal (InfoPrint 1832, 1852, and 1872) 4-38
Operator panel hinge assembly, left removal (InfoPrint 1832, 1852, and 1872) 4-40
Operator panel hinge assembly, right removal (InfoPrint 1832, 1852, and 1872) 4-41
Pick arm assembly removal (InfoPrint 1832, 1852, and 1872) 4-43
Pick roll assembly removal (InfoPrint 1832, 1852, and 1872) 4-45
Print cartridge cooling fan removal (InfoPrint 1832, 1852, and 1872) 4-45
Print cartridge clamp assembly removal (InfoPrint 1832, 1852, and 1872) 4-46
Print cartridge ID connector assembly removal (InfoPrint 1832, 1852, and 1872) 4-47
Printhead assembly removal (InfoPrint 1832) 4-48
Printhead assembly removal (InfoPrint 1852 and 1872) 4-49
Connection access cover, rear removal (InfoPrint 1832, 1852, and 1872) 4-51
Connection bezel assembly, rear removal (InfoPrint 1832) 4-51
Connection bezel assembly, rear removal (InfoPrint 1852 and 1872) 4-52
Door assembly, rear removal (InfoPrint 1832, 1852, and 1872) 4-53
Duplex guide assembly, rear removal (InfoPrint 1852 and 1872) 4-53
Cover assembly, rear lower removal (InfoPrint 1832) 4-55
Cover assembly, rear lower (InfoPrint 1852 and 1872) 4-55
Redrive motor assembly removal (InfoPrint 1852 and 1872) 4-56
Side cover, right removal (InfoPrint 1832) 4-58

service-repairmanual.com

fineline6

Side cover, right removal (InfoPrint 1852 and 1872) 4-59
Sensor (duplex input) removal (InfoPrint 1852 and 1872) 4-59
Sensor (media level) removal (InfoPrint 1832, 1852, and 1872) 4-60
Sensor (media out) removal (InfoPrint 1832, 1852, and 1872) 4-60
Sensor (toner empty) removal (InfoPrint 1832, 1852, and 1872) 4-61
Sensor (input) removal (InfoPrint 1832, 1852, and 1872) 4-61
Sensor shield assembly removal (InfoPrint 1832, 1852, and 1872) 4-62
Standard bin actuator assembly removal (InfoPrint 1832, 1852, and 1872) 4-63
Sensor (standard bin exit) removal (InfoPrint 1832, 1852, and 1872) 4-63
Sensor (toner density) removal (InfoPrint 1832, 1852, and 1872) 4-64
Switch (media size) assembly removal (InfoPrint 1832, 1852, and 1872) 4-64
LVPS card assembly removal (InfoPrint 1832) 4-65
LVPS card assembly removal (InfoPrint 1852 and 1872) 4-68
Access door removal (InfoPrint 1832, 1852, and 1872) 4-70
System card assembly removal (InfoPrint 1832, 1852, and 1872) 4-71
Transfer roll assembly removal (InfoPrint 1832, 1852, and 1872) 4-74
Transfer roll bracket assembly, left removal (InfoPrint 1832, 1852, and 1872) 4-75
Transfer roll bracket assembly, right removal (InfoPrint 1832, 1852, and 1872) 4-76
Transfer deflector removal (InfoPrint 1832, 1852, and 1872) 4-77
Redrive assembly removal (InfoPrint 1832, 1852, and 1872) 4-78
Option removals 4-79
High capacity input tray 4-79
High capacity input tray (HCIT) media tray assembly removal 4-80
High capacity input tray (HCIT) tray cover, front removal 4-81
High capacity input tray (HCIT) cover, rear removal 4-83
High capacity input tray (HCIT) cover, right removal 4-85
High capacity input tray (HCIT) cover, left removal 4-87
High capacity input tray (HCIT) anti-tip latch assembly removal 4-89
High capacity input tray (HCIT) drawer slide assembly removal 4-90
High capacity input tray (HCIT) tray lift drive motor assembly removal 4-91
High capacity input tray (HCIT) controller card assembly removal 4-92
High capacity input tray (HCIT) media size actuator assembly removal 4-93
Sensor (HCIT tray raised HP) with cable assembly removal 4-95
Sensor (HCIT pass through) with cable removal 4-97
High capacity input tray (HCIT) pick arm bracket assembly removal 4-98
High capacity input tray (HCIT) tray closed latch with spring removal 4-100
250-sheet media tray assembly removal 4-101
250-sheet option drawer assembly removal 4-101
250-sheet pick arm bracket assembly removal 4-102
250-sheet media out actuator removal 4-103
Anti-tip latch assembly removal 4-103
250-sheet frame assembly removal. 4-104
Sensor (pass through) with cable removal 4-105
250-sheet controller card assembly removal 4-108
Media size actuator removal 4-110
Media tray catch spring removal 4-111
Tray roller catch assembly removal 4-113
550-sheet option tray assembly 4-114
550-sheet media tray assembly removal 4-115
550-sheet option drawer assembly removal 4-115
550-sheet pick arm bracket assembly removal 4-116
550-sheet bellcrank recoil spring removal 4-117
Media out actuator removal (InfoPrint 1852 and 1872) 4-117
Anti-tip latch assembly removal 4-118
550-sheet frame assembly removal 4-119
Upper interface cable assembly removal 4-121
Lower interface cable assembly removal 4-121
Sensor (pass through) with cable removal 4-122
550-sheet controller card assembly removal 4-122

service-repairmanual.com

fineline6

Media size actuator removal 4-124
550-sheet option drive shaft with spring removal 4-125
Media tray catch spring removal 4-126
Media tray roller catch assembly removal 4-126
Stapler finisher rear door assembly removal 4-127
Stapler finisher right cover removal 4-127
Stapler finisher left cover removal 4-127
Stapler finisher top cover removal 4-127
Stapler finisher handle cover removal 4-127
Stapler finisher ADF output bin removal 4-127
Stapler finisher LED sensor cover removal 4-127
Stapler finisher sensor (finisher bin media present) removal 4-127
Stapler finisher standard output bin LED and LED clear lens removal 4-128
Stapler finisher tamper recoil spring removal 4-128
Stapler finisher tamper drive belt removal 4-128
Stapler finisher tamper drive motor assembly removal 4-128
Stapler finisher media stack flap and media stack flap actuator removal 4-128
Stapler finisher stapler unit assembly removal 4-128
Stapler finisher bin spring removal 4-128
Stapler finisher controller card assembly removal 4-129
Stapler finisher paddle drive motor assembly removal 4-129
Stapler finisher sensor (media stack) removal 4-129
Stapler finisher sensor (paddle HP) removal 4-129
Stapler finisher sensor (stapler access door interlock) removal 4-129
Stapler finisher sensor (tamper HP left and right) removal 4-129
Stapler finisher sensor (bin full send) removal 4-129
Stapler finisher sensor (bin full receive) removal 4-129
Stapler finisher sensor (media in stapler) removal 4-130
Stapler finisher stapler cover removal 4-130
Stapler finisher sensor (diverter HP) removal 4-130
High capacity stacker rear door assembly removal 4-130
High capacity stacker right cover removal 4-130
High capacity stacker left cover removal 4-130
High capacity stacker media output bin recoil spring (left and right) removal 4-130
High capacity stacker standard output bin LED removal 4-131
High capacity stacker media output bin assembly removal 4-131
High capacity stacker controller card cover panel removal 4-131
High capacity stacker switch (media bin HP) removal 4-131
High capacity stacker sensor (media bin full) assembly removal 4-131
High capacity stacker sensor (media bin full) bracket assembly removal 4-131
High capacity stacker controller card assembly (upper and lower) removal 4-131
High capacity stacker right frame removal 4-132
High capacity stacker left frame removal 4-132
High capacity stacker upper diverter gate removal 4-132
High capacity stacker sensor (pass through) removal 4-132
High capacity stacker left mounting bracket removal 4-132
High capacity stacker upper diverter spring removal 4-133
High capacity stacker sensor (diverter gate HP) removal 4-133
5-bin mailbox rear door assembly removal 4-133
5-bin mailbox left outer cover removal 4-133
5-bin mailbox left inner cover removal 4-133
5-bin mailbox right outer cover removal 4-133
5-bin mailbox right inner cover removal 4-133
5-bin mailbox top cover removal 4-133
5-bin mailbox media bin full actuator removal 4-134
5-bin mailbox sensor (pass through) removal 4-134
5-bin mailbox sensor (media bin empty) removal 4-134
5-bin mailbox controller card assembly removal 4-134
5-bin mailbox static brush mylar assembly removal 4-134

service-repairmanual.com

fineline6

5-bin mailbox media bin fifth diverter removal 4-134
5-bin mailbox media bin first through fourth diverter removal 4-134
5-bin mailbox upper diverter spring removal 4-135
5-bin mailbox media bin extension assembly removal 4-135
5-bin mailbox output bin LED bracket removal 4-135
5-bin mailbox diverter gate solenoid removal 4-135
5-bin mailbox transport solenoid removal 4-135
5-bin mailbox sensor (diverter gate HP) removal 4-135
5-bin mailbox output bin LED assembly removal 4-136
Output expander rear door assembly removal 4-136
Output expander left outer cover removal 4-136
Output expander left inner cover removal 4-136
Output expander right outer cover removal 4-136
Output expander right inner cover removal 4-136
Output expander media bin latch (left and right) removal 4-136
Output expander media output bin assembly removal 4-137
Output expander media bin full actuator removal 4-137
Output expander sensors (media bin full) assembly removal 4-137
Output expander sensor (media bin full) bracket assembly removal 4-137
Output expander controller card cover panel removal 4-137
Output expander controller card removal 4-137
Output expander standard output bin LED removal 4-138
Output expander sensor (pass through) removal 4-138
Output expander diverter gate removal 4-138
Output expander upper diverter gate spring removal 4-138
Output expander sensor (diverter gate HP) removal 4-138
. 4-138

Connector locations and connections 5-1

Connections 5-1

Preventive maintenance 6-1

Safety inspection guide 6-1
Lubrication specifications 6-1
Scheduled maintenance 6-1
Maintenance kit 6-1

Parts catalog 7-1

How to use this parts catalog 7-1
Assembly 1: Covers 7-2
Assembly 2: Operator panel 7-4
Assembly 3: Drive motor assemblies and duplex 7-6
Assembly 4: Media path and ducts 7-8
Assembly 5: Printhead, fuser assembly, and electronics 7-10
Assembly 6: Pick arm assembly and MPF 7-12
Assembly 7: 250 Sheet option tray assembly 7-14
Assembly 8: 550 Sheet option tray assembly 7-18
Assembly 9: HCIT Sheet option tray assembly 7-20
Assembly 10: Finisher assembly #1 7-22
Assembly 11: Finisher assembly #2 7-24
Assembly 12: 5-bin mailbox 7-26
Assembly 13: High capacity stacker 7-28
Assembly 14: Output expander 7-30
Assembly 15: Envelope feeder and external duplex 7-32
Assembly 16: Electrical cables 7-34

Index I-1

Part number index I-5

service-repairmanual.com

fineline6

service-repairmanual.com

fineline6